



Floating Spray Fountain with LED Lights FTC102 Instruction Manual Please Read Before Use

The floating spray fountain comes with a submersible LED light ring, a transformer, a buoy, a pump, a string and an anchor.

Connect the pump hose to the nozzle inlet pipe by tightening the hose clamp clockwise.

Fountain floats freely in water. To keep it from moving, you should use the string, tie one end underneath the buoy and the other end to an anchor, adjust the length of string to ground anchor and keep the fountain from moving.

Fountain water spray is about 3 Ft height and 2.5 Ft width.

Fountain pump and LED light have separate plugs. Light can be on or off while fountain is running.

For best results the water pump should be cleaned once a month or as conditions call for depending on your water source conditions. When cleaning, make sure to remove any dirt that is blocking the water inlet to keep the spray fountain operating smoothly.

Warning

For your safety, unplug all power connections before doing any work on the fountain. Do not get into or touch the water where the fountain is operating.

