



Camera component description

1. 20m/66ft cable
2. Underwater Camera with White LEDs
3. Stainless Steel Ballast
4. Video output jack
5. DC 12V Power Plug
6. Extra DC 12V Power Plug (Not require to use)



Connection



- Plug the 4 point DC connector (D) into your power source (such as the Main Power Adaptor (B), Cigarette Light Adaptor (C) or if you have a 12V battery you can connect that as well) and then into the Underwater Camera's Power Jack (5).
- Plug the camera's Male RCA Video (4) connector into the Female RCA Video "In" connector on your VCR, TV, LCD monitor or Digital Camera (provided that it has an RCA input).
- The second DC power plug can be connected to your 12V Viewing Device, such as a portable LCD screen.